


# Instruction of WIFI Controller for inverter models



INSTALLATION  
AND USER GUIDE



VERZE 17. 01. 2020 / 05. 03. 2020

EN


# Index

1.	How to replace the controller with WIFI .....	3
2.	About "Alsavo Pro" app .....	4
3.	"Alsavo Pro" app Operation .....	5

# 1.



## How to replace the controller with WIFI

1.1 Open the waterproof box, then disconnect the cable, and take off the original controller.



1.2 Re-connect cable of new controller with the WIFI as below.

The WIFI antenna could be hidden in the controller box. Lastly fix the controller with WIFI back in the box.



## 2.

## About "Alsavo Pro" app

Thank you for using the heat pump with WIFI controller,you can remotely control your pool heat pump from your smart phone.The controller information could syncs to"Alsavo Pro" APP via an internet connection (WIFI or 3G/4G). For the first time connection, your smart phone and the WIFI controller must be under the same WIFI network. From then on, your smart phone can use the 3G/4G network to control pool heat pump remotely.

By "Alsavo Pro" APP,you can turn heat pump on or off, adjust water temperature,change mode, timer setting, parameter setting and malfunction checking. It's just right at your finger tips.

- ➔ "Alsavo pro" APP is compatible with Android system and IOS system.
- ➔ Currently 10 languages (English, Swedish, French, Spanish, Italian, Czech, Polish, German, Russian, Chinese) are available.
- ➔ Several heat pumps with WiFi controller could connect to one phone's app, and several phones' app could connect one heat pump.
- ➔ Both ON/OFF and Inverter pool heat pump can be applied to App 'Alsavo Pro', when the first time 'Alsavo Pro' connect to the machine, it identifies the heat pump is ON/OFF or inverter then display the related interface.



## "Alsavo Pro" app Operation

3.1 Firstly search & download the "Alsavo Pro" APP from App store or Google play in your smart phone.

3.2 Open the "Alsavo Pro" app.

Click "+" on the upper left and select the "New device". Then Click "Next" and Enter the current WIFI password to connect.

Then press „⏻“ 5S on the display firstly, then enter the current WIFI password. The display will show F1 1, F1 2.....F1 6, which means the connect is OK.

**If the connection fails, the APP will indicate "Failed to connect device".**


„Nickname and password" interface only appear one time when new heat pump first successful connection. You can name and encrypt this unit. (If unsteady WIFI network, this interface may be missing. You will miss a chance to name and encrypt it. In this case, default password "123456" is available.)

If someone's app is in the same WIFI network as yours, his app could automatically identify your heat pump. And he can operate your heat pump after inputting your password.







### 3.3 The main interface (inverter)

#### 1) Turn ON/OFF



Click the „“ to turn on or off the heat pump.


#### 2) Switch the working mode



There are three modes (Auto mode, cooling or heating) for the inverter unit. Click its icons to switch ( Auto mode,  Heating,  Cooling)




#### 3) Timer Setting



Click , at first time, it turns . Timer on and off will be activated together. Then choose desired time in "timer on" and "timer off", lastly click "OK" to confirm.

Click „“ again, timer on and off will be disable.



#### 4) Parameter checking and setting

Click Parameter  then enter the Password "0757". It includes Parameter query and setting.




**Parameter setting:**

1) There are 2 modes option for Water pump operating (1:Always running, 0:Depends on the running of compressor)

2) Inlet water temperature calibration: (-9.0 -9.0°C)

3) Temperature unit: °C or °F.

4) When do the re-set to factory default setting, pop-up tips whether you want to reset it.




Parameter Query		Default setting
Water In	22°C	
Water Out	22°C	
Heating pipe temperature	22°C	
Limited frequency code	0	
Ambient temperature	23°C	
Exhaust temperature	21°C	
Actual steps of electronic expansion valve	350	
IPM module temperature	25°C	
Compressor working frequency	0Hz	
Compressor current	0A	
DC fan motor speed	0RPM	
Parameter Setting	Range	

Ambient temperature	23°C
Exhaust temperature	21°C
Actual steps of electronic expansion valve	1
IPM module temperature	25°C
Compressor working frequency	0Hz
Compressor current	0A
DC fan motor speed	0RPM
Parameter Setting	Range
Water pump operating mode	0(0 - 1)
Inlet water temperature calibration	0.0°C(-9.0 - 9.0°C)
Temperature Unit	°C
Re-set to factory default setting	

**(5) Switch the running modes**

In heating or cooling mode, there are 3 running modes (Silent, Smart, Powerful) for options

While in Auto mode, its default running mode is Smart.



**6) Malfunction**

If error occurs, the Malfunction icon turns red . Click it to check the Error.

Error code	Malfunction
PP01	Inlet water temperature sensor failure
PP02	Outlet water temperature sensor failure
PP03	Heating coil pipe sensor failure
PP04	Gas return sensor failure
PP05	Ambient temperature sensor failure
PP06	Exhaust temperature sensor failure
PP07	Anti-freezing protection in Winter
PP08	Low ambient temperature protection
PP10	Coil pipe temperature too high protection under Cooling mode
PP11	T2 too low water temperature protection under cooling mode
EE01	High pressure failure
EE02	Low pressure failure
EE03	Water flow failure
EE04	Water temperature overheating protection under heating mode
EE05	Exhaust temperature too high failure
EE06	Controller malfunction or communication failure
EE07	Compressor current protection
EE08	Communication failure between controller and PCB
EE09	Communication failure between PCB and driver board
EE10	VDC Voltage too high protection
EE11	IPM Module protection
EE12	VDC Voltage too low protection

EE13	Input current too strong protection
EE14	IPM module thermal circuit is abnormal
EE15	IPM module temperature too high protection
EE16	PPC module protection
EE17	DC fan failure
EE18	PPC module thermal circuit is abnormal
EE19	PPC module high temperature protection
EE20	Input power failure
EE21	Software control failure
EE22	Current detection circuit failure
EE23	Compressor start failure
EE24	Ambient temperature device failure on Driving board
EE25	Compressor phase failure
EE26	4-way valve reversal failure
EE27	EEPROM data reading failure in Transfer board
EE28	The inter-chip communication failure on the main control board

**7) Set the desired temperature**

You can set the target water temperature by adjusting the slider or press „◀“ or „▶“


The setting water temperature on the controller display correspondingly changes after letting go. When the setting water temperature on the display changes, it will be synchronously updated to the APP.



**8) Check device information.**

In the main interface, click the upper right “Alsavo Pro”. The Device info will show up.

With the serial number and password, others could connect this unit by choosing the existing device.



**9) Revise the heat pump info in the homepage**

Click „✎” you could rename, change its password and delete the device.

In the communication, APP act as a host, while the display as a slave:

1. When the parameters are modified in the APP, accordingly it will be updated in the display.
2. When the parameters changes in the display, also it will be updated in the APP.









# Notes

A series of horizontal dashed lines for taking notes.

Thank you  
for using ALBIXON  
products



**ALBIXON**  
Call centrum: 477 07 07 11  
[www.ALBIXON.com](http://www.ALBIXON.com)

Note that the photos used in the manual are illustrative only. Printing and typesetting errors reserved.